

Sennheiser ME3 Andrea USB Adapter Combo

Congratulations on your purchase of a Sennheiser ME3 Microphone!

This is an extremely high quality and durable microphone that provides excellent accuracy and noise cancelation when used with speech recognition software. This microphone is not compatible with all PC sound cards and is often best used with an external sound adapter.

Using the ME3 with an Andrea USB Sound adapter:

1. Connect as shown below; drivers will be automatically installed



2. If using this set-up with Dragon NaturallySpeaking, it is necessary to select the Andrea USB adapter as your preferred audio device. In Window XP it will show up as "AK5370" and in Windows 7 and Vista it will show up as "USB Audio Device" Although you can simply run the audio set-up wizard with your current user profile, it is best to add a new "source" to an existing user profile. This is done as follows:

Dragon 10 and Earlier: Go to Dragon > Open User > Source > New.

Dragon 11: Go to Profile > Add Audio Source to Current User Profile

For more information, refer to our "Microphone Set-Up and Troubleshooting Guide" (link on the bottom of home page at www.SpeechRecSolutions.com).

Mounting the microphone to your head: In general, the velcro strap offers no particular function and can be discarded. Mounting of the microphone is not always intuitive. Refer to the diagram to the left for help if needed.



Positioning: The foam covered microphone element should be about $\frac{1}{2}$ to $\frac{3}{4}$ of an inch from the right front of your mouth, and ideally to the side of your mouth. If necessary, bend the flexible boom to get the proper position. If you get warnings of excessively high or low sound levels when performing the Audio Set-up Wizard with NaturallySpeaking, simply move the microphone slightly further away or closer as appropriate.

Warranty: 2-year Sennheiser warranty.